

POWERSPORT SERIES BATTERY UPGRADE REFERENCE CHART



LITHIUM	HIGH PERFORMANCE AGM	AGM READY TO GO	LOCALLY ACTIVATED AGM UPGRADE	LOCALLY ACTIVATED AGM	LOW MAINTENANCE CONVENTIONAL	HIGH PERFORMANCE CONVENTIONAL	CONVENTIONAL
PAL4LHY	-	PTX4LBS-FS	-	PTX4L-BS	-	CB4L-A	-
PAL4LHY	-	PTX4LBS-FS	-	PTX4L-BS	-	CB4L-B	-
-	-	-	-	-	-	CB5L-B	12N5-3B
PAL5LHY	-	PTX5LBS-FS	-	PTX5L-BS	-	-	-
-	-	-	-	-	-	CB7L-B	12N7-3B
-	-	-	-	-	-	CB7-A	12N7-4A
PAL7ZSHY	-	-	-	-	-	CB7C-A	-
PAL7AHY	-	PTX7ABS-FS	-	PTX7A-BS	-	-	-
PAL7ZSHY	-	PTX7LBS-FS	-	PTX7L-BS	-	-	-
PAL7ZSHY	-	PTZ7S	-	-	-	-	-
-	-	-	-	PT9A-BS	-	CB9-B	12N9-4B-1
-	-	-	-	-	-	CB9L-B	12N9-3B
-	-	-	-	-	-	CB9L-A2	12N9-3A-1
PAL9HY	-	PTX9BS-FS	-	PTX9-BS	-	-	-
PAL14-AHY	-	-	-	-	-	CB10A-A2	-
-	-	PTX12AABS-FS	-	-	-	CB12A-A	12N12A-4A-1
PAL12HY	-	PTX12ABS-FS	-	PTX12A-BS	-	-	-
PAL14ZSHY	-	PTX12BS-FS	-	PTX12-BS	-	-	-
PAL12HY	-	PTZ10S	-	-	-	-	-
PAL14ZSHY	-	PTZ12S	-	-	-	-	-
PAL14ZSHY	-	PTZ14S	-	-	-	-	-
PAL14-AHY	-	PTX14AHBS-FS	-	PTX14AH-BS	-	CB14-A2	-
PAL14-AHY	-	PTX14AHBS-FS	-	PTX14AH-BS	-	CB14-B2	-
PAL14-AHY	-	PTX14AHBS-FS	-	PTX14AH-BS	-	CB14A-A	-
PAL14-AHY	-	PTX14AHBS-FS	-	PTX14AH-BS	-	CB14A-A2	-
PAL14L-AHY	-	PTX14AHLBS-FS	-	PTX14AHL-BS	-	CB14L-A2	12N14-3A
PAL14L-AHY	-	PTX14AHLBS-FS	-	PTX14AHL-BS	-	CB14L-B2	-
PAL14L-AHY	-	PTX14AHLBS-FS [†]	-	PTX14AHL-BS [†]	-	SCB14L-A2	-
PAL14L-AHY	-	PTX14AHLBS-FS [†]	-	PTX14AHL-BS [†]	-	SCB14L-B2	-
PAL14L-AHY	-	-	-	-	-	CB14L-A1	-
PAL14HY	PTZ16H	PTX14BS-FS	-	PTX14-BS	-	-	-
PAL14LHY	-	PTX14LBS-FS	-	PTX14L-BS	-	-	-
-	-	PTX15LBS-FS	-	PTX15L-BS	-	-	-
PAL16HY	-	-	PTX20CH-BS	PTX16-BS	-	-	-
-	-	PTX19BS-FS	-	PTX19-BS	CB16-B-LM	CB16-B	-
-	-	PTX19LBS-FS	-	PTX19L-BS	CB16HL-A-LM	-	-
-	-	PTX19CLBS-FS	-	PTX19CL-BS	-	CB16CL-B	-
-	-	PTX19LBS-FS	-	PTX19L-BS	-	CB16L-B	-
-	PTX20HBS-FS*	PTX20BS-FS*	-	PTX20-BS*	-	CB18-A	-
PAL20LHY	PTX20HLBS-FS*	PTX20LBS-FS*	-	PTX20L-BS*	-	CB18L-A	-
-	-	-	-	PIX50-BS	-	C50-N18A-A	-
PAL50N18L-AHY	-	PIX50LBS-FS*	-	PIX50L-BS#	C50-N18L-A-LM#	C50-N18L-A3	-
PAL50N18L-AHY	-	PIX50LBS-FS**	-	PIX50L-BS# [†]	-	SC50-N18L-AT	-
PAL30LHY-H	PIX30HLBS-FS/ PIX32HLBS-FS	PIX30LBS-FS	-	PIX30L-BS	-	CB30L-B	-
PAL30LHY-H	-	PIX30CLBS-FS	-	PIX30CL-BS	-	CB30CL-B	-
-	PIX30HLBS-FS/ PIX32HLBS-FS	PIX30LBS-FS	-	PIX30L-BS	-	C60-N24AL-B	-
-	-	51913-FS	-	-	-	51913	-
PAL30LHY-H	PIX30HLBS-FS/ PIX32HLBS-FS	PIX30LBS-FS	-	PIX30L-BS	-	53030	-

GLOBAL HEADQUARTERS (USA AND INTERNATIONAL EXCLUDING EMEA)

Power-Sonic Corporation
365 Cabela Dr Suite 300,
Reno, Nevada 89523
USA
T: +1 619 661 2020
E: customer-service@power-sonic.com

POWER-SONIC EMEA (EMEA – EUROPE, MIDDLE EAST AND AFRICA)

Smitspol 4, 3861 RS Nijkerk,
The Netherlands
T NL: +31 33 7410 700
T UK: +44 1268 560 686
T FR: +33 344 32 18 17
E: salesEMEA@power-sonic.com

[†] Eliminates need for sensor (needs to be disabled).

* The PTX20 series batteries may be used as an optional upgrade, but some modification to the hold down may be necessary. See battery label for retrofit cautions.

Top and front terminal mounts only.

‡ Top and side terminal mounts only.

FURTHER INFORMATION

Please refer to our website www.power-sonic.com for product catalogs, safety data sheets (SDS), ISO certification, etc.